





DT2

DT - domácí telefon
4 FP 210 52, 37, 211 02
a se zábranou odposlechu
4 FP 210 38, 110 73





DT1




ZT - zvonkové tlačítko

BZ - bytový zvonek
4 FN 605 11,13
17,19



TT 94 s KZ (kódovačem)

Elektrický zámek EZ
4 FN 877 01,02,03
4 FN 877 11,12,13,14



u () a [] chybí
oba na svorku -



Síťový zdroj
4 FP 672 55
(4 FP 672 39,40)
[4 FP 672 18]

230V/50Hz

n = počet DT